

 vornadobaby

Owner's Handbook

read & save these important instructions

manual del propietario
lea y guarde estas instrucciones importantes

mode d'emploi
lire et conserver ces instructions importantes



HELLO, I'M
Sunny

nursery heater

Hola, me llamo Sunny, calefactor de cuartos de niños. Bonjour, je suis le ventilateur chauffant Sunny CS,

Welcome to Vornadobaby

Thank you for choosing to put a Vornadobaby product in your nursery. Our goal is to provide healthy, comfortable air - through every season. Vornado has been doing this for quite a while now. We've brought all our experience in air health and comfort, and tailored it exclusively for your nursery.

A THIRD
generation
NAME

Vornado



 vornadobaby™

Vornado began in 1945, continues to revolutionize airflow today and is now tailored for the nursery.

Contents

| | |
|-------------------------------------|----|
| Important Safety Instructions | 4 |
| Safety..... | 8 |
| Sunny Controls..... | 9 |
| Plug In & Placement..... | 10 |
| How To Use..... | 12 |
| Keeping Sunny Clean..... | 14 |
| Tips | 15 |
| Troubleshoot | 16 |
| Warranty..... | 18 |

READ ALL INSTRUCTIONS BEFORE USING THIS HEATER

IMPORTANT SAFETY INSTRUCTIONS

This owner's guide and any additional inserts are considered part of the product. They contain important information about safety, use and disposal. Before using the product, please familiarize yourself with all operating and safety instructions. Please keep all documents for future reference and pass these documents on, together with the product, to any future owner. See our website to view, download and print the most current version of this owner's guide.

INTENDED USE: This product is intended to heat and circulate the air in indoor living spaces only. This product is not intended for commercial or industrial use. The manufacturer assumes no responsibility for damage or injury due to unauthorized use or product modification. Failure to follow these directions will void the product warranty.

WARNING: Risk to Children and Impaired Persons

- Extreme caution is required during the installation, operation, cleaning and maintenance of this product by or around children under age 12 and anyone with reduced physical, sensory or mental capabilities. Children should be supervised to ensure that they do not play with the appliance, its parts and packaging material.

INSTALLATION WARNING – To reduce risk of fire, electrical shock and injury to persons, observe the following:

- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- Do not use this heater in an RV, boat or during any application where battery power is converted to AC power.
- Place this product at least 3 feet away on all sides from, electrical outlets, furniture, pillows, bedding, papers, clothes, curtains and other objects that may cause or catch on fire. Do not place the heater near a bed because objects such as pillows or blankets can fall off the bed and be ignited by the heater.
- To prevent a possible fire, do not place the heater on soft surfaces, like a bed, where air intakes or exhaust can be blocked in any manner.
- No part of this product (the appliance, power cord, plug, packaging, etc.) should be placed near furnaces, fireplaces, stoves or other high temperature heat sources. Do not use in a window, on an uneven or unstable surface, or near water.
- The appliance, power supply, power cord and plug cannot come into contact with water. Do not use this product on wet surfaces. Do not use this product in a bathtub or shower or position product where it may fall into a bathtub, laundry, swimming pool or other water container. Do not use this product outdoors or expose it weather or elements.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over. The cord should not

hang over edges of counters or be placed where it can be cramped or closed in doors. Place appliance near an easily accessible outlet so the product can be unplugged quickly during an emergency.

SAFE USE WARNING – To reduce risk of fire, electrical shock and injury to persons, observe the following:

- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- Extreme caution is required at all times a heater is in operation. Always unplug heater when not in use. Vornado does not recommend unattended and unsupervised use of this heater.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. If provided, use handles when moving this heater.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip). Do not use this heater on a surge-protected unit or Ground Fault Circuit Interrupted (GFCI) outlet. Note: GFCI outlets are typically found in bathrooms and kitchens and feature a "reset" button to prevent tripping of an electrical circuit.
- Before plugging power cord into electrical outlet, be sure that all electrical information on the rating label, including voltage, is compatible with your outlet's power supply.
- **WARNING:** To reduce likelihood of circuit overload, fire and electric shock, do not operate with a solid state speed device, such as a dimmer control switch. Use of this appliance on the same electrical circuit as another high energy use product,

such as a vacuum cleaner, blender, variable speed fan or circular saw is not advised. Do not use this heater with a timer designed to automatically turn the unit on or off, as this may accidentally disable the heater's thermal cutout safety feature.

- Risk of fire. Do not operate if it has been dropped or if damage is apparent to any part of the unit including the cord and plug. Only original replacement parts may be used.
- Never use the cord as a handle or otherwise yank, strain or stretch the power cord.
- While the product is plugged in, do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- Check your heater cord and plug connections. A loose fitting outlet can cause the plug to overheat or cause a fire. Be sure plug fits tight in the outlet. Check frequently during use to make sure plug and outlet are not hot. If so, discontinue using heater and have outlet replaced by a qualified electrician.
- Never ignore the signs of an electrical problem, such as: warm outlet coverplates, sparks when plugging in or operating, lights flickering/dimming during operation. Immediately turn off and unplug the appliance if any such problems are noticed. Contact a qualified electrician to investigate possible causes before operating the appliance again.
- **Note:** Heaters draw more current than small appliances, overheating of the outlet may occur even if it has not occurred with the other appliances.
- This heater is for use with 120 volt electrical outlets. The cord has a plug as shown at A in Figure 65.1, below. An adapter as shown at C is available for connecting three-blade grounding-type plugs to two-slot receptacles. The green grounding

lug extending from the adapter must be connected to a permanent ground such as a properly grounded outlet box. The adapter should not be used if a three-slot grounded receptacle is available.




Figure 65.1

- Before moving, repositioning, servicing, cleaning and when not in use, use the product controls to turn off the power and then unplug. To disconnect from outlet, grasp and pull only the plug. Also, power off and unplug if the product will be left unattended for an extended period of time or during electrical storms.
- If your heater suddenly stops working:
 - This heater is equipped with a thermal cutout safety feature designed to automatically shut off when overheating is detected. See the "RESET HEATER" instructions in this guide to determine how to check and reset the heater.
 - If the heater and other electrical products suddenly stop working at the same time, your home circuit breaker or fuse may have tripped due to an overload of power. Consider only running your heater on the "low" setting, only running one heater at once and unplugging all other electrical products while running the heater, and/or hiring an electrician to install an additional circuit to your

home's electrical system.

SERVICING WARNING – To reduce risk of fire, electrical shock and injury to persons, observe the following:

- Clean your product regularly, only as is instructed in this manual. Prior to cleaning, turn off the power on your product and unplug. Do not use gasoline, thinners, solvents, ammonias or other chemicals for cleaning. Refer to the CLEANING instructions provided.
- Do not open appliance housing while product is plugged in. To avoid risk of shock, all service and/or repairs must be done by a Vornado Authorized Service Center.

DISPOSAL WARNING

To reduce waste and environmental harm, observe the following:



PACKAGE RECYCLING: The packaging protects the appliance from transport damage. The packaging materials are selected from the point of view of their environmental friendliness and disposal technology and are therefore recyclable. Dispose of all packaging materials in an environmentally responsible manner.

FCC CONSUMER ADVISEMENT: This equipment may generate, use and/or radiate radio frequency energy that may cause harmful interference to radio communications. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to contact Vornado Consumer Service.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

SAVE THESE INSTRUCTIONS

Safety

Plug It In Safely! Your Sunny has a 6 ft. power cord, covered for additional safety. Vornado recommends placing product as close to an outlet as possible and securing the remaining cord.



Child Locking Switch

Keeps Sunny Off when not in use.



Auto Shutoff

If airflow becomes blocked and overheating occurs, the heating element will shut off.



Finger Friendly Design

Resists curious fingers.



Topple Protection

Sunny will automatically shut off if tipped over.



Cool Touch Case


Safe to touch, even on high heat setting.



Covered Power Cord Storage

Safely store power cord inside base of Sunny.

Sunny Controls



① Power (⏻)

② Heat (☀️)

③ Fan (🌀)

④ Thermostat (1-7)

⑤ Lock Arm (🔒)


Plug In & Placement

Power Cord Storage

For your convenience and safety the Power Cord Storage keeps the power cord neat and out of harms way.

1. Lift the Power Cord Storage flap to locate plug, then unwind the power cord stored inside.


Safety Tip: Power cords increase strangulation risks. Secure as much excess cord as possible inside the Power Cord Storage.



Set Up

1. Position your Sunny so the vortex beam of air is directed across the room, unobstructed.
2. Plug power cord into grounded wall outlet.


Safety Tip: It is best to position Sunny close to the power outlet and store excess power cord inside the Power Cord Storage.




How To Use

Locking Controls

1. To unlock this feature first pivot the Lock Arm (🔒), then press the Power switch (⏻) On. The red light will illuminate when On.




2. To disengage this feature press the Power switch Off and the Lock Arm will automatically protect the Power switch.



Operation

1. Select Heat setting (⏻). Low Heat (I) 450 watts or High Heat (II) 900 watts.

Note: It is normal for the exit air from the heater to feel cooler on low heat than on high heat.




2. Select Fan setting. In the Auto position (🌀), the fan will cycle on and off with the heating element. In the Continuous position (∞), the fan will run continuously and the heating element will cycle on and off.



- 3.** Set Thermostat. Turn knob to desired comfort level. Monitor the desired setting and adjust Thermostat accordingly.



- 4.** For fan use only without heat, select Fan Only on the Thermostat and Continuous on the Fan.




Keeping Sunny Clean

Cleaning the Grill

- 1.** Power Sunny Off and unplug.
- 2.** Use the brush attachment on your household vacuum cleaner to vacuum any accumulated dust on the unit or wipe down the entire surface with a soft cloth.

Note: Do not use gasoline, thinners, solvents or other chemicals for cleaning.



Always unplug Sunny before starting any part of the cleaning process.

Tips

Resetting Your Vornado Heater

Your Vornado Sunny has a multi-level safety shut-off system designed to prevent overheating. If this happens, the safety shut-off system will cut power to the heat element and you will need to manually reset Sunny.

1. Press Power Switch Off and unplug Sunny.
2. Remove any obstructions and wait 5-10 minutes, allowing Sunny to cool down.
3. Plug in Sunny and press Power Switch to On. Your Vornado Sunny is ready.

Note: If the safety shut-off system repeatedly shuts off Sunny or if it will not reset, DO NOT ATTEMPT TO DISASSEMBLE SUNNY. Call Vornado Consumer Services toll-free at 1-800-234-0604.

- During the off-season or after extended periods of non-use, you may choose to store Sunny. To ensure long life of the product, it is recommended to store Sunny by following these instructions:
 - Unplug power cord and wrap cord neatly inside the Power Cord Storage.
 - Thoroughly clean Sunny. Use the brush attachment on your household vacuum cleaner to vacuum any accumulated dust on Sunny or wipe down the entire surface with a soft cloth. You may also use a can of compressed air for debris.
 - Always set Power switch to Off and unplug Sunny before cleaning.
 - Cover, or place Sunny back into retail carton if available. This will prevent Sunny from accumulating dust over time.
 - Store Sunny in a cool and dry location.
- The motor is permanently lubricated and requires no oiling. Do not use gasoline, thinners, solvents or other chemicals for cleaning.

Troubleshoot

| | |
|---|--|
| Unit fails to power on. | Unit is not plugged in. Plug Power Cord into electrical outlet. |
| | Household circuit breaker / ground fault interrupter has tripped or blown a fuse. Reset circuit breaker / ground fault interrupter, or replace fuse (See IMPORTANT SAFETY INSTRUCTIONS). |
| | The unit has overheated. Automatic Safety Shut-Off has initiated (See RESETTING YOUR VORNADO HEATER). |
| Unit is not producing sufficient amount of heat. | Unit is damaged or in need of repair. Cease usage and unplug. Contact Consumer Service for assistance. |
| | Ensure unit is set to High Heat and thermostat is set to highest Temperature setting. |
| | Close all doors and windows to contain heat. |
| | Allow the unit to fully circulate the heat throughout the room, may take several minutes. |

**Unit power on
but there is no
heat.**

Power off and unplug the unit. On the bottom of the unit, there is a gray tip over switch. Push in 4-5 times ensuring it is not stuck. Set unit down on flat surface. Be sure power cord is not under unit. Plug unit in and power on. Turn to highest heat setting.



Happy Parent Guarantee

Call Toll Free

800.234.0604

vornadobaby.com

support@vornadobaby.com

If you're not satisfied with this product, let us know. We'll go the extra mile to ensure you're a happy Vornadobaby parent!

Vornado Air LLC ("Vornado") warrants to the original consumer or purchaser this Vornadobaby® Sunny Nursery Heater ("Product") is free from defects in material or workmanship for a period of five (5) years from the date of purchase. If any such defect is discovered within the warranty period, Vornado, at its discretion, will repair or replace the Product at no cost.

For warranty or repair service:

Call 1-800-234-0604 or email support@vornadobaby.com to obtain a Return Authorization ("RA") form. Please have or include your Product's model number and serial number, as well as your name, address, city, state, zip code and phone number when contacting Vornado for warranty service.

After receiving the RA form, ship your Product to:

Vornado Air LLC Attn: Warranty & Repair 415 East 13th Street Andover, KS 67002 For your convenience, please have your model number and serial number when contacting Vornado with service inquiries. To assure proper handling, packages must be clearly marked with the RA number. Packages not clearly marked with the RA number may be refused at the receiving dock. Please allow 1-2 weeks for repair and return of your Product after the Product is received.

Product registration available online at www.vornadobaby.com

Repairs not covered by the warranty or outside the warranty period will require a fee to cover the cost of materials, labor, handling and shipping. This warranty does not apply to defects resulting from abuse of the Product, modification, alteration, mishandling, improper maintenance, commercial use or repair or service of the Product by anyone other than Vornado; damages which occur in shipment or are attributed to acts of God. Improper product use, which includes using an external device that alters or converts the voltage or frequency of electricity, or shipping a Vornado product to a country

not intended for use will void all warranties. Any unauthorized product modification, repair by unauthorized repair center or use of non-approved replacement parts is not recommended and any consequences will not be covered by support services or product warranties. The product warranty will be honored only on models that are being used in the country intended. REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. VORNADO SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT, EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY. Some states do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state. The manufacturer assumes no responsibility for damage or injury caused by failure to follow these instructions, improper product use or unauthorized product modifications. Any such actions will invalidate the product warranty.

All company names and product names are trademarks of their respective owners. © All rights reserved. All technical information, data and instructions for the installation, connection and operation contained in these instructions for use correspond to the latest available information at time of printing. The contents of this manual may differ slightly from the actual product. Observe any additional supplements.



Designed, engineered and supported in Andover, KS

© 2017 Vornado Air LLC Andover, KS 67002 Patent US 9,620,311 B2 and U.S. Patent Pending. Specifications subject to change without notice. Vornado® and Vornadobaby® are trademarks owned by Vornado Air LLC.



Speak your mind vornadobaby.com/reviews
Hable con franqueza vornadobaby.com/reviews
Exprimez-vous! vornado.com/reviews

Vornado Air, LLC
415 East 13th Street, Andover, Kansas 67002
800.234.0604
vornadobaby.com
support@vornadobaby.com